



# NORWOOD COUNTACASH INSERT INSTRUCTIONS

REMOVABLE  
NOTE  
PARTITIONS



5¢ COIN COUNTER COUNTS	\$1.00
10¢ COIN COUNTER COUNTS	\$2.00
20¢ COIN COUNTER COUNTS	\$2.00
\$2.00 COIN COUNTER COUNTS	\$20.00
\$1.00 COIN COUNTER COUNTS	\$10.00

When last coin exceeds height of existing roll, the protruding coin should be removed.



Removable note partitions:  
bend forward and pull upward.  
*Note:* If coins are placed in incorrect  
dispensers, incorrect amounts will be calculated.

*Australian Designed and Manufactured*