LM/TM-30xx, 31xx Series LCD Monitor User's Manual Rev. Ori



FCC NOTICE

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with limits for a Class A digital device pursuant to subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures to correct the interference.

WARRANTY LIMITS

Warranty will terminate automatically when the machine is opened by any person other than the authorized technicians. The user should consult his/her dealer for the problem happened. Warranty voids if the user does not follow the instructions in application of this merchandise. The manufacturer is by no means responsible for any damage or hazard caused by improper application.

ABOUT THIS MANUAL

This manual assists the user to utilize the (Touch) Monitor TM(LM)30xx/31xx series. This product provides exquisite touch control capability over a stable and adjustable LCD monitor with minimal footprint.

The manufacturer of the LM/TM30xx /31xx series monitor heartily apologizes to the user for reserving the right to change or to modify this manual without notice due to the rapid and constant progress and improvement on science and technology. The user may always obtain the most up to date information through any of our web sites: <u>http://www.posiflex.com</u>,

http://www.posiflex.com.tw, http://www.posiflexusa.com.

© Copyright Posiflex Technology, Inc. 2014

TRADE MARKS AND SERVICE MARKS

POSIFLEX is a registered trademark of Posiflex Technology, Inc.

P/N: 19600904010

Other brand and product names are trademarks and registered trademarks and service marks of their respective owners.

I. PRODUCT MODEL NUMBER

Model Name	Screen Size	Touch Function	Stand Alone	Rear Cover Mount	Max Resolution Supported	МЕМО
LM-3010F/HS	9.7"	N/A			1024x768 pixels	For HS series
LM-3010F-B/HS	9.7"	N/A			1024x768 pixels	For HS series
LM-3010F/KS	9.7"	N/A			1024x768 pixels	For KS series
LM-3010F-B /KS	9.7"	N/A		V	1024x768 pixels	For KS series
LM-3010F LM-3010F-B	9.7"	N/A		V	1024x768 pixels	For XT series
TM-3010F TM-3010F-B	9.7"	Yes		V	1024x768 pixels	For XT series

TM-3010F/HS	9.7"	Yes			1024x768	For HS
				•	pixels	series
TM-3010F-B/HS	9.7"	Yes			1024x768	For HS
					pixels	series
TM-3010F/KS	9.7"	Yes			1024x768	For KS
					pixels	series
TM-3010F-B/KS	9.7"	Yes			1024x768	For KS series
LM-3014F	14"	N.T./ A			pixels 1366x768	For XT
LM-3014F LM-3014F-B	14	N/A		\checkmark	pixels	For XI series
LM-3014F-B/KS	14"	NT/A			1024x768	For KS
LWI-30141'-D/KS	14	N/A		\checkmark	pixels	series
TM-3014F	14"	Yes			1024x768	For XT
TM-3014F-B	11	105		v	pixels	series
TM-3014F/KS	14"	Yes			1024x768	For KS
				, ,	pixels	series
TM-3014F-B/KS	14"	Yes			1024x768	For KS
					pixels	series
LM-3015F/KS	9.7"	N/A			1024x768	For KS
					pixels	series
LM-3015F-B/KS	9.7"	N/A			1024x768	For KS
					pixels	series
LM-3015F	15"	N/A		\checkmark	1024x768	For XT
LM-3015F-B	0.5%				pixels	series
LM-3110 LM-3110-B	9.7"	N/A	\checkmark		1024x768 pixels	
TM-3110	9.7"	T.			1024x768	
TM-3110-B	9.7	Yes	\checkmark		pixels	
LM-3114	14"	N/A			1366x768	
LM-3114-B	17		v		pixels	
TM-3114	14"	Yes			1366x768	
TM-3114-B					pixels	
LM-3115	15"	N/A			1024x768	
LM-3115-B					pixels	
TM-3115	15"	Yes			1024x768	
ТМ-3115-В					pixels	

II. FEATURES

- Bezel free monitor.
- High quality TFT LCD panel.
- Easy maintenance structure allowing easy cleaning and tilt adjustment.
- VESA mounting supported for all series.

• Support power supply through VGA cable from Posiflex POS Terminal.

Power Setup Notice

 $\sqrt{10}$ For rear mount device, it is designed for use with a Posiflex system. In such application, it can utilize power support from the Posiflex system. Standalone device is equipped with its power adaptor.

III. CARTON CONTENTS


- 1. Monitor/Touch Monitor
- 2. User's Manual
- 3. VGA cable
- 4. USB signal cable (for TM series only)
- 5. A Posiflex information CD (for all TM series)
- 6. Optional +DC 12V power adaptor & power cord


IV. PARTS IDENTIFICATION


* LED INDICATOR STATUS


Color Status	Working	Stand-by	Off
Model	Croon	Orongo	Nona
LM/TM-3010 Series	Green	Orange	None
LM/TM-3014 Series	Green	Orange	None
LM/TM-3015 Series	Blue	Green	None
LM/TM-3110 Series	Green	Orange	None
LM/TM-3114 Series	Green	Orange	None
LM/TM-3115 Series	Blue	Green	None


A. FRONT VIEW













Rear Cover Mount LM/TM-3010/HS




Joint Bracket For HS series POS system



Rear Cover Mount LM/TM-3010/KS




Joint Bracket For KS series POS system




Stand alone LM/TM-3110/3110-B





Plastic Neck_ Cover



Stand alone LM/TM-3115/3115-B/3114/3114-B








V. Hardware Installation LM/TM-3010/3014/3015 Series for XT Series


Please do the following steps to install LM/TM-3010/3014/3015 series:

Step A): Place the XT system on a soft pad and align the main unit along table to easily adjust the bracket

of 2nd LM LCD panel unit to the suitable angle for installation.




Step B): Please locate the 4 holes on the rear side of the host system.



Step C): Adjusting the bracket to the suitable angle, please take the 2nd LM LCD display bracket, aim its 4 holes and tighten the indicated screws to the system.



Step D): The assembly is completed below.



LM/TM-3110/3110-B Series

A. TILTING LCD PANEL

Please do the following steps to tilt LCD panel:


Step A): Hold and push downward the main unit.



Step B): Tilt the neck at its right position for most suitable angle for best view effect and convenience in cable connection/disconnection.

B. CONNECTING ALL CABLES

With the LCD monitor/touch monitor panel turned to most backward position, the main I/O connector area will be easily accessible at bottom side of the main unit. **Please first note orientations of every existing cable connection** and then connect every cable properly before any further reconfiguration of cable connections.




C. OPENING PLASTIC NECK COVER

To route through base, please observe the below side view pictures of the base trunk and release the triangle marked hooks to remove the plastic neck cover.



D. CABLE ROUTING IN BASE


For cable routing in the mini slim base, please refer to the picture below. Have all cables pass through the oval hole on the trunk as triangle marked to come out of the arrowed cable exit hole on the base rear side of trunk. Then connect all the cables ends to main unit.



LM/TM-3010/KS for KS Series

Please do the following steps to install LM/TM-3010/KS:

Step A): Fasten the 4 screws onto the upper rear bracket of KS series machine.Then Hold the LM-3210/KS monitor with bracket, aim to join the upper rear bracket then fasten the 3 screws onto the indicated holes.



Step B): Connect the VGA Cable to the LM VGA port and route the VGA cable through the cable exit hole of KS base stand to the system VGA port on the I/O plate.

LM/TM-3010/HS for HS Series

To mount LM-3010/HS on the back of the terminal, please do the following steps to tilt LCD panel:

Step A): Release the top cover on the HS system top I/O plate.

Step B): Adjust the rear bracket of 2nd display to its adequate angle, connect one VGA cable end at the 2nd display VGA port, the other at the VGA port on the top I/O plate by routing thru the cable exit hole.


B)

Apply carefully the 4 small screws that come along with the 2nd display series to the back of this terminal at the screw hole circled in the below picture.


Step C): Close the rear bracket cable cover as illustrated.


A)

C)









Note: Do not overdo the tightening or unrecoverable thread damage will occur.

LM/TM-3114/3114-B/3115/3115-B Series

A. TILTING LCD PANEL

Please do the following steps to tilt LCD panel:

Step A): Hold and push downward the main unit indicated

Step B): Tilt the neck at its right position for most suitable angle for best view effect and convenience in cable connection/disconnection.

B








B. CABLE ROUTING

Please do the following steps to remove the cable cover for Gen 7 slim base model.

Step A): Release the base cover.

Step B): Release the base stand neck cover.

Step C): Route the cable to the circled holes.



VI. OSD Menu Introduction


Power & OSD buttons

The buttons at the right side of LCD monitor are for the OSD (On Screen Display) control operations and LCD screen power control as in the below picture and are explained below.

"OSD" button: To enter OSD menu

- "EXT" button: To Exit the option functions
- " + " button: To increase setting; auto tune feature.





Once one icon is selected, it will be displayed in inverted color to indicate its relationship with the submenu below. On the physical panel side bar of LCD monitor display pressing "EXT" button will shift the

monitor display, pressing "EXT" button will shift the selected icon one by one from left to right and then wrap around to the leftmost part. Press "OSD" button to enter the selected sub menu. Items in sub menu are illustrated below. Press "+"/"-" to adjust.

** "BRIGHTNESS / CONTRAST ADJUST SUBMENU": There are 2

icons in this submenu:

*BRIGHTNESS ADJUST": When this item is selected, there will be only the brightness icon with an adjustment indication bar under it between the main menu area and the video signal mode. Press "+" button to increase brightness intensity. Press "-" button to decrease brightness intensity. Press OSD/EXT to save/exit.


Ģ

Å

CONTRAST ADJUST": When this item is selected, there will be only the contrast icon with an adjustment indication bar under it between the main menu area and the video signal mode. Press "+" button to increase contrast intensity. Press "-" button to decrease contrast intensity. Press OSD/EXT to save/exit.

"IMAGE POSITION": There are 2 icons in this submenu:

"Horizontal Position": When this item is selected, there will be only the position icon with an adjustment indication bar for user to adjust. Press "+" button to move image rightward for horizontally rightward positioning. Press "-" button to move



compact product detail about resolution and refresh rate for demonstration.



"Menu Language : Change Language of Menu": When this item is selected, there will show a multilingual menu for user to opt for desired language option.

Haglish	Français	Italiano	简体中文
Español	日本語	Deutsch	Русский



"Menu Position" (reserved)



Note: This "Menu Position" is reserved. "Factory Default": When this item is selected, there will show a Factory Default menu for user to restore to original monitor settings below.



"Accessibility": When this item is selected, there will show an Accessibility menu for user to change menu time-out setting.

"EXIT": Exit OSD setup with all adjustment saved.

SUPPORTED DISPLAY MODES

For VGA signals beyond the supported display modes, there will be a message "Out Of Range" on the middle of screen. Maximum supported color depth for 10" and 14" monitor model is 18 bits or 262,144 colors. Color depth 15" is 24 bits or Supported display modes are illustrated in the table:

Display Resolution	Refresh Rate (Hz)	Horizontal Frequency (KHz)
640*400	70	37.9
	60	31.5
640*480	72	37.9
	75	37.5
720*400	70	37.9
	56	35.1
800*600	60	37.9
800,000	72	48.1
	75	46.9
	60	48.4
1024*768	70	56.5
	75	60
1366*768	60	47.7

Note: Only the LM/TM-3014/3114 series is supported for the optimal 1366*768 resolution.

SPECIFICATION

Display	LM/TM 3014 series
LCD Panel	14" TFT LCD
Resolution	1366 (H) x 768 (V)
Active Area (mm)	309.399 (H) x 173.952 (V)
Pixel Pitch (mm)	0.2265 (H) x 0.2265 (V)
Pixel Arrangement	RGB Vertical Stripe
Viewing Angle (Typical)	20/45/45/45 degree (U/D/L/R)
Contrast Ratio (Typical)	650 : 1
Response Time (Typical)	4 ms (Rising) / 6 ms (Falling)
Brightness (Typical)	200 cd/m^2
Touch	
Touch Type	Bezel free resistive (for TM3014)
Interface	USB (for TM3014)
General Specification	

Display Interface	VGA
Power Supply	12V from Posiflex terminal VGA port

Display	LM/TM 3015 series		
LCD Panel	15.0" TFT LCD		
Resolution	1024 (H) x 768 (V)		
Active Area (mm)	304.128 (H) x 228.096 (V)		
Pixel Pitch (mm)	0.297 (H) x 0.297 (V)		
Pixel Arrangement	RGB Vertical Stripe		
Viewing Angle (Typical)	80/80/80/80 degree (U/D/L/R)		
Contrast Ratio (Typical)	600 : 1		
Response Time (Typical)	3 ms (Rising) / 5 ms (Falling)		
Brightness (Typical)	250cd/m2		
Touch			
Touch Type	Bezel free resistive (for TM3015)		
Interface	USB (for TM3015)		
General Specification			
Display Interface	VGA		
Power Supply	12V/50W from Posiflex terminal VGA port		

Display	LM/TM 3010/3110 series
LCD Panel	9.7" TFT LCD
Resolution	1024 (H) x 768 (V)
Active Area (mm)	196.61 (H) x 147.46 (V)
Pixel Pitch (mm)	0.192 (H) x 0.192 (V)
Pixel Arrangement	RGB Vertical Stripe
Viewing Angle (Typical)	70/70/70/60 (U/D/L/R)

Contrast Ratio (Typical)	500 : 1	
Response Time (Typical)	20 ms (Rising plus Falling)	
Brightness (Typical)	270 cd/m^2	
Touch		
Touch Type	Bezel free resistive (for TM3010/3110)	
Interface	USB (for TM3010/3110)	
General Specification		
Display Interface	VGA	
Power Supply	12V/18W from Posiflex terminal VGA port	

USB Touch Manager

USB Touch Manager for each type of touchscreen is available for user to set up touchscreen functions. If your system is preloaded with the OS of your choice, the Manager will be installed on your system. Nevertheless, you can also download the Manager from our website:

1. Visit us at <u>http://www.posiflex.com</u>, and click **Support** on the main menu bar.